

GARRETT VENT | EXTERNAL WASTEGATES

High flowing external wastegates for turbocharged racing and performance engines




Spring Pressure Chart

Spring Pressure Chart

										BASE PRESURE							
GVW-40	PSI	3	4	6	7	9	10	12	13	14.5	16	17	19	20	22	23	25
	Bar	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	1.6	1.7
Red		x					x	x			x						
Blue			x						x	x		x			x	x	x
Green				x			x		x				x			x	
White					x			x						x	x		x
Brown						x				x					x		
Purple											x	x	x	x		x	x

GVW-45 GVW-50	PSI	3	4	6	7	9	10	12	13	14.5	16	17	19	20	22	23
	Bar	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1.1	1.2	1.3	1.4	1.5	1.6
Blue		x				x	x		x	x	x				x	x
Green			x						x			x	x		x	
White				x		x		x		x				x		x
Brown					x		x	x	x	x	x	x				
Purple													x	x	x	x
Black											x	x	x	x	x	x

Spring pressures are calculated based on a 1:1 boost/backpressure ratio. Actual intake manifold (boost) pressure can vary



Watch the Install Video

Garrett
ADVANCING MOTION