



Quickstart Guide Shift light

Provided accessories


- Shift light module with connecting cable

More information


More information on the display and other products and accessories you can find online at:

www.canchecked.de www.canchecked.de/shiftlight

Connection MFD28



Connection MFD15



5V (orange): C6 Ground (black): C12 Shift (blue): C11

Installation

The shift light with its 20inch (50cm) connecting cable can be position freely in your car. Recommended place is near the speedometer or on top of the steering column. Please make sure the cable is not pulled during operation or even rubs at the steering. Make sure the display is shutdown during installation. Pull the bigger plug from the backside of the display and push in the cable pins in the positions mentioned above:

1) Orange: 5V

2) Black: ground

3) Blue: shift

Push plug back to its position.



Implementation

After the first start of your MFD28 tap the screen once and head to the "menu" (on top of the display) and to "Shift light". Here you can set up the RPM steps and colour for each LED.

If you use a MFD15 click your encoder once and go to "STP" and click again. Navigate to "settings" – "shift light" and you will find the same options.

With the option "RPM test", you can simulate RPM and have a look, how the shift light behaves. If the colours do not match, please adjust the "shift type" under "Other" until they fit.

"Rpm Blink" specifies the RPM blink functionality. When reaching this RPM count, the shift light will flash.

You can also specify the direction of the shift light under "Other" – either left to right or right to left.

After finishing your setup do not forget to hit the "Save" button.

Touch areas on the screen



- 1) RPM steps and LED colours
- 2) Further options
- 3) Navigation

On questions regarding accessories or functionality please get in contact with us via our homepage (www.canchecked.de) or via email (info@canchecked.de).