

# ALS Tire Pro Install Guide (20.06.2022)

V1.0 – Initial version

# 1. Overview


The case needs to be drilled for M2 screws (1.6 drill bit) using the supplied template. The thickness of the case is 2mm and the drill bit isn't allowed to go past 3mm (so 1mm clearance inside) as it can hit the battery and the silicone seal around the sensor.



The recommended way would be to remove the PCB and silicone seal, but, if you can drill the holes to be 2-3mm, you can jump straight to step #3 in the guide

## 2. Taking the sensor apart

Unscrew the 3 x M2 screws of the case and gently lift the lid.




Remove the two screws that fix the PCB to the case and gently push the camera and silicone seal out



### 3. Drilling the holes

Drill the 2 holes using the supplied template. They need to be tapped for M2 screws, so use a 1.6 drill bit.



Fit the lens into the mount and put everything in place using the M2 screws provided.

